

## MAINTENANCE

## **Scheduled Maintenance Chart**

ITEM	SERVICE	FIRST 10-20 HOURS	EVERY 25 HOURS <sup>1</sup>	EVERY 75 HOURS	EVERY 100 HOURS	EVERY 300 HOURS or ANNUALLY	EVERY 2 YEARS
Engine Oil & Filter	Change	X (Oil)	X (Oil)	X (Oil)			
ZF Transmission Fluid	Change	Х				Х	
Indmar V-Drive Fluid	Change	Х				Х	
Engine Coolant	Check/Change					Check	Change
Spark Plugs*	Change					Х	
Fuel Injectors*	Inspect/Clean					Х	
Fuel Filter*	Replace					Х	
Flame Arrestor	Clean/Change				Х		
Belts	Inspect	Х			Х	Х	
Shaft Alignment	Check	Х				Х	
Spark Plug Wires*	Inspect					Х	
Raw Water Pump Impeller	Inspect				Х	Replace	
Breather Hose*	Clean					Х	
Starter Bendix*	Grease			Х		Х	
Heat Exchanger	Inspect/Clean					Х	
Zinc Anodes	Inspect			Х			

\* Services best accomplished by your Indmar dealer.

<sup>1</sup> Severe use applications (see special note on previous page)